



## Undermount Fireclay Sink Installation

In an Undermount installation the countertop flows over the edge of the sink and the sink is supported from beneath.



**Step 1: Countertop Cut-Out.** It's best to wait till you have the sink on location to measure for the cut out. Use precise measurements.

**Step 2: Supporting the Sink.** Mount the undermount installation kit (Model #: **ABUMSB**) to the inner side walls of your cabinet. We then recommend putting plywood on the rods to create a large smooth flat surface. Drill the necessary drain holes. If you did not purchase the kit you will need to create a custom support using 2x4's.

**Step 3: Leveling.** Slide your sink in and make sure it is leveled on bottom and top. Make adjustments if necessary.

**Step 5: Sealing.** Using a silicone sealer seal all edges of the sink to the countertop to prevent water from leaking into your cabinet.