

Installation Instructions



Installation Instructions

1. Insert the securing bracket under the upright locking rod. Slide the bracket, centering the operating handle hub between the bracket's curved hooks.
2. Slide the housing (deflector shield on top) onto the extended end of the bracket.
3. Insert the no shackle lock in the cavity. Secure the two sections aligning the holes.

Instructivo de instalación

1. Inserte el corchete que asegura bajo la barra que bloquea vertical. Resbale el corchete, centrando el cubo de la manija de funcionamiento entre los ganchos curvados los corchetes.
2. Resbale la cubierta (blindaje de la desviación en tapa) sobre el extremo extendido del corchete.
3. Inserte el bloqueo del grillo de no en la cavidad. Asegure las dos secciones que alinean los agujeros.

Instructions d'installation

1. Insérez la bride de fixation sous l'anse de verrouillage verticale. Faites glisser la bride de façon à centrer le moyeu du manchon opératoire entre les doigts recourbés de la bride.
2. Faites glisser le boîtier (chicane en haut) sur le bout avancé de la bride.
3. Insérez le cadenas sans anse dans la cavité. Fixez les deux sections en alignant les trous.