

Model RDIN-00

Installation Instructions

Ranger[®]
Deadbolt[™]

INNERBOLT



Installation Instructions

1. Place bracket on rear door. Install four self-tapping screws.
2. Drill ½" hole in center of bracket pin hole in floor (or roof).
3. Insert pin.

Instructivo de instalación

1. Coloque corchete en la puerta trasera. Instale cuatro tornillos.
2. Taladre ½" hoyo en el centro de hoyo de alfiler de corchete en el piso (o el techo).
3. Inserta alfiler.

Manufactured to exclusive specifications in China for Ranger Lock.
Gainesville, GA - USA 866-988-LOCK (5625) www.rangerlock.com

Ranger[®]
Lock