

- First start by using the appropriate ESCO tie rod end removal tool to separate the tie rod from the spindle, drag link, etc.
- Next start by installing the ESCO tie rod socket onto the end of an impact or hand wrench.
- Determine the thread direction required for removal.
- Begin supplying power to the Tie Rod Socket. The tie rod should now loosen and spin off from the rod.

NOTE: If the tie rod end does not easily come off the rod, remove any power or force from the tool and apply a penetrating lubricant to the threads of the item to be removed. Wait a few minutes before attempting to use the tool again.

PARTS BREAKDOWN



(1) HEAVY DUTY TIE ROD SOCKET