
XTo prevent irregular winding of the wire rope around the drum, keep the fleet angle 2 degrees or less. Please install the pulley 6ft or more away from the drum


on the center line of the drum.

改訂/REVISION

XThe value of specified "Wire Rope Tension" on this drawing is for the standard layer or less.

The value of the "Wire Rope Tension" must be decreased accordance with the ratio of the actual winding layers, if it exceeded.





MODEL GM-3-GS-SI

松嶺