


RENEWING YOUR SOFTWARE LICENSE




1 

If you do not already have the WebVT update software installed. Visit: webvt.ateq-tpms.com
If Installed, skip to step 5

2 


Select the location on your PC that you wish to save the WebVT file.

3 


Once the download is finished, locate the file and double-click the WebVT.exe icon.

4 

Follow the instructions in the installation file to finish installing WebVT.


5 

Once finished, a shortcut will appear on your PC desktop. double-click WebVT.


6 

TPMS tool information	
Device	TPMS tool
Serial number	B366-34424
Software version	DH1-25-04
Available version	DH1-25-04
License	01 January 2021

Connect your tool to your PC via USB cable. Once connected, all of the tool's information will be displayed, including the software subscription date.

7 

At the top of the screen, select the "Renew License" Icon.

8 

A Popup will appear instructing you to enter the software license code. Once entered, press OK. Your software license subscription will be updated and the new subscription date will appear in "TPMS tool information".