

OPERATING INSTRUCTIONS

Heavy Duty Tie Rod End Remover
 Commercial Set **MODEL 40315**

- Start by selecting the appropriate socket according to pin size.
- Once you have found the correct socket, place the socket onto the leaf spring pin.
- Using air ratchet or impact tool, thread out the desired pin.
- Once completed remove socket.

PARTS BREAKDOWN



REF NO.	PART NO.	DESCRIPTION	QUANTITY
1	40315-1	7/8"-14UNF	1
2	40315-2	3/4"-16UNF	1
3	40315-3	M20*P1.5	1
4	40315-4	M16*P1.5	1
5	40315-5	1/2"-20UNF	1