



## Western Enterprises

875 Bassett Road  
Westlake, OH 44145-1142

**Toll Free:** 800.783.7890

**Phone:** 440.871.2160

**Email:** [sales@westernenterprises.com](mailto:sales@westernenterprises.com)

**Website:** [www.westernenterprises.com](http://www.westernenterprises.com)

### ITEM # 872, CGA-500 MEDICAL MIXTURES CYLINDER TO CGA-540 OXYGEN REGULATOR ADAPTER

Adapters connect a regulator to a cylinder or other equipment when different CGA threads on the mating parts make a direct connection impossible.

Adapters must be selected with care to ensure that regulators and other equipment are used only with compatible gases and pressure ratings.

A mixture of non-compatible gases in any system is a possible hazard. Regulators and all other parts of an adapted system must be thoroughly purged of all contaminants, especially organic material and residual gases.

[+ more](#)



[Specifications](#) | [Additional Information](#) | [Prop 65](#)

#### Specifications

Field	Industrial
Material	Brass
From Cylinder Service	CGA-500 Medical Mixtures
To Regulator Service	CGA-540 Oxygen
Cylinder Nut	500-2
Cylinder Nipple	15-8
Regulator Adapter	415-1

#### Additional Information

##### Additional Information

Adapters should not be used as permanent installations. For long-term use, the appropriate CGA regulator should be used on all cylinders and gas systems.

**Prop 65**

**Warning**

This product can expose you to lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm.