



Western Enterprises

875 Bassett Road
Westlake, OH 44145-1142

Toll Free: 800.783.7890

Phone: 440.871.2160

Email: sales@westernenterprises.com

Website: www.westernenterprises.com

ITEM # 873, CGA-500 MEDICAL MIXTURES CYLINDER TO CGA-580 NITROGEN REGULATOR ADAPTER

Adapters connect a regulator to a cylinder or other equipment when different CGA threads on the mating parts make a direct connection impossible.

Adapters must be selected with care to ensure that regulators and other equipment are used only with compatible gases and pressure ratings.

A mixture of non-compatible gases in any system is a possible hazard. Regulators and all other parts of an adapted system must be thoroughly purged of all contaminants, especially organic material and residual gases.

[+ more](#)



[Specifications](#) | [Additional Information](#) | [Prop 65](#)

Specifications

Field	Industrial
Material	Brass
From Cylinder Service	CGA-500 Medical Mixtures
To Regulator Service	CGA-580 Nitrogen
Cylinder Nut	500-2
Cylinder Nipple	15-8
Regulator Adapter	416-1

Additional Information

Additional Information

Adapters should not be used as permanent installations. For long-term use, the appropriate CGA regulator should be used on all cylinders and gas systems.

Prop 65

Warning

This product can expose you to lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm.