

1/4" LONGFRAME 489 SERIES

PROGRAMMING INSTRUCTIONS

HOW TO IDENTIFY A PROGRAMMABLE PATCHBAY

489 Series programmable patchbays can be identified by the Programmable Icon in the upper left corner of the patchbay.



HOW TO CHANGE THE PROGRAMMING FOR A CIRCUIT

- 1: Remove the top designation strip, as shown in the photo on the right.
- 2: Find your desired configuration in the diagram.
- 3: Arrange the programming shunts to match the appropriate diagram. Note: Each circuit can be programmed independently.
- 4: Ample shunts are provided with every patchbay. Red shunts are placed horizontally and are used for normaling. White shunts are placed vertically and are used for grounding.
- 5: The circuits are numbered 1-24 and correspond to vertical jack pairs reading left to right.
- 6: Replace the designation strip.

SHUNT SCHEMATICS

