

# Clips

## Product Specifications

<b>Width</b>	Approx. 1.25"
<b>Length</b>	Approx. 4.25"
<b>Weight</b>	0.025 lbs
<b>Max spacing</b>	48" on center
<b>Recommended load</b>	36 lbs ~ 3 (5/8") Type X Drywall layers
<b>Max safe load</b>	46 lbs ~ 4 (5/8") Type X Drywall layers
<b>Fail load</b>	300 lbs ~ 27 (5/8") Type X Drywall layers


Clip Configuration	Trade Names	Image
Single Part Clip	Whisperclip RC Architectural Clip	
Two-Part Clip	Whisperclip Noiseproofing Clip	

## Green Glue Noiseproofing Clip Layout

- **(1)** Clips are spaced no further than 48" apart horizontally
- **(2)** Hat channel must not be spaced more than 24" vertically
- **(3)** Bottom clips must be less than 3" from the floor
- **(4)** Top clips must be less than 6" from the ceiling\*

Clips must be placed at the outermost studs on every piece of hat channel

*\*For ceiling installation, the same pattern is used. However, the 3" minimum spacing should be used at the drywall edges to ensure proper support for the sheet, not 6" as used for walls.*




Layout pattern for Green Glue Noiseproofing Clips

## Step 1

Measure for placement of Green Glue Noiseproofing Clips using layout guidelines listed above. Mark locations and install clips using appropriate screws.

## Recommended screws by stud type

<b>Wood</b>	Use #8 × 1-5/8" or longer
	Coarse thread screws
<b>Steel</b>	Use #8 × 1-1/4" or longer
	Type S self tapping screws
<b>Concrete</b>	Use 3/16" dia × 2-1/4"
	Tapcon or equal anchor screw



Install ceiling drywall before walls by butting ceiling drywall to studs



Step 1

Outermost clips must be spaced at every interval.

# Clips *(continued)*

## Step 2

Snap appropriate hat channel into clips

### Recommended hat channel

<b>Size</b>	20-25 gauge hemmed edges
<b>Depth</b>	7/8"
<b>Width top</b>	1-1/4"
<b>Width bottom</b>	2-1/2"

Most walls will require you to overlap hat channel, instructions for doing so are as follows.

- Overlap 6 inches of hat channel between two clips.
- Secure the hat channel with two 7/16" screws or per code.
- Final depth from drywall to studs in total is typically 1-3/8" (37 mm) for 1 part clip, or 1-5/8" (43 mm) for 2 part clips.

## Step 3

Place shims on the floor to allow spacing between the drywall and the flooring. This ensures decoupling from the floor to make it impossible for vibrations to travel from wall to floor and vice-versa.

Screw drywall in place through hat channel. Be sure drywall is fully installed before removing shims from underneath.

## Step 4

Be sure to use an acoustical sealant to fill gaps around electrical boxes and areas below or above sheets of drywall. Green Glue Noiseproofing Sealant is perfect for this application as it allows flexibility while stopping sound from transmitting through unsealed areas.

Visit [www.greengluecompany.com/FAQs](http://www.greengluecompany.com/FAQs) for further information.



Scan QR code to see how to apply the Green Glue Noiseproofing Clip.



Step 2: Snap hat channel into clips



Step 3: Raise the drywall into place



Step 4: Fill gaps between drywall

DISCLAIMER: Because of the many installation variables beyond our control, Green Glue Company shall not be liable for incidental and consequential damages, directly or indirectly sustained, nor for any loss caused by application of these goods not in accordance with current printed instructions or for other than the intended use. Our liability is expressly limited to replacement of defective goods. Any claims shall be deemed as waived unless made in writing to Green Glue Company within thirty (30) days from the date it was discovered, or reasonably should have been discovered.